



Franklin[®]

2 IN 1 SPRING SWING

14574


Phase 2

INSTRUCTION SHEET

Parts List:



Base (1pc)



Power Tee (2pcs)
Pre-assembled
Replacement Part
#14574-R2




Joint (1pc)
Replacement Part
#14574-R1

Assembly Instructions:

Step (1) Remove all parts from the display box to ensure that you have all of the parts listed.

Step (2) Place the joint in the base and twist to lock into place.

Step (3) Insert the bottom of the power tee into the joint and twist to lock in place.



Step (4) Adjust the tee to the proper height using a twist and lock motion. The tee adjusts from 22in (55.9cm) to 28in (71.1cm)

Step (5) The 360 degree joint is designed to prevent the tee from tipping over. The tee will automatically return to the original hitting position.

Step (6) The 2 in 1 easily adjusts from a tee to pop up. To use the pop up function simply press the top of the tee downward and place the ball on the tee. The timed release gears will automatically pop the ball up. **Now you are ready to play!**

